

---

# Harley-Davidson "Aggressor" Series V-Rod Headlight Fairing 2009-2017



## Mounting instructions

---

1. Check all clearances before, during and after installation.
2. Disconnect the plugs from the front headlamp. Carefully dismount the headlamp. Dismount the headlamp brackets from the bike.
3. Attach the headlamp to the included bracket using two included M6x16 button head bolts as shown on the Fig.1



Fig. 1



Fig. 2

4. Attach the fairing to the bracket using three included M6x16 button head bolts as shown on the Fig.2
5. Mount the assembly on the bike. In the top position the assembly is fixed to the upper triple tree with two M8x20 button head bolts (see Fig. 3).



Fig. 3



Fig. 4

6. In the bottom position the assembly is fixed to the lower triple tree through two oval holes using button head bolts bushings nuts and washers (see Fig. 4).
7. Connect the wiring plugs in to the headlamp. Adjust the headlight and the installation is complete.
8. After the installations test the lights to be sure everything is working perfectly.

### NOTE:

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.

**Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.**