

---

# Harley-Davidson Bagger Touring 08-20 Brake Caliper Extension Brackets 13" Rotors Mounting instructions

---



1. Check all clearances before, during and after installation.
2. Remove the break calipers from the front fork.
3. Bolt the extension brackets to the front fork. Use the included M10x30 bolts, apply the thread locker glue.
4. Screw the brake calipers to the extensions. Use the included M10x35 bolts, apply the thread locker glue.
5. After the installation make a test drive to be sure everything is working perfectly.

**NOTE:**

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.



**Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.**

---

# Harley-Davidson Bagger Touring 08-20 Brake Caliper Extension Brackets 13" Rotors Mounting instructions

---



1. Check all clearances before, during and after installation.
2. Remove the break calipers from the front fork.
3. Bolt the extension brackets to the front fork. Use the included M10x30 bolts, apply the thread locker glue.
4. Screw the brake calipers to the extensions. Use the included M10x35 bolts, apply the thread locker glue.
5. After the installation make a test drive to be sure everything is working perfectly.

**NOTE:**

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.



**Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.**