
Harley-Davidson "Aggressor" Series V-Rod fork Cover Set Mounting instructions



1. This instruction is for the full Cover set, however, if you bought only caps or middle or lower covers, just follow appropriate parts of the instruction.
2. Check all clearances before, during, and after installation.
3. Raise the front of the motorcycle enough to take the front wheel off. Make sure it won't fall during all operations. Take the front wheel off following H-D factory service manuals.
4. Take both front fork tubes assemblies off following H-D factory service manuals.
5. Assemble the fork tubes back putting them through the middle and lower parts of fork covers. If included, put the o-ring at the lower part of the middle cover. Note that the middle covers' ends are angled, just turn them around their axis until you find the right position. The lower fork cover part has the cutout; during the montage ensure it is orientated inside the motorcycle.
6. After putting front fork tubes assemblies back on the motorcycle check all bolting is screwed according to the H-D factory service manuals!
7. Adjust the positions of the fork covers checking all clearances and fix those using fixing screws. Use the thread locker (not included).
8. Put the front wheel back on the motorcycle following H-D factory service manuals.
9. Put the fork cover caps on the top of the fork tubes. Fix those with screws and thread locker. Now the installation is complete.
10. After the installations test drive the bike to be sure everything is working perfectly.

NOTE:

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.

Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.

Harley-Davidson "Aggressor" Series V-Rod fork Cover Set Mounting instructions



1. This instruction is for the full Cover set, however, if you bought only caps or middle or lower covers, just follow appropriate parts of the instruction.
2. Check all clearances before, during, and after installation.
3. Raise the front of the motorcycle enough to take the front wheel off. Make sure it won't fall during all operations. Take the front wheel off following H-D factory service manuals.
4. Take both front fork tubes assemblies off following H-D factory service manuals.
5. Assemble the fork tubes back putting them through the middle and lower parts of fork covers. If included, put the o-ring at the lower part of the middle cover. Note that the middle covers' ends are angled, just turn them around their axis until you find the right position. The lower fork cover part has the cutout; during the montage ensure it is orientated inside the motorcycle.
6. After putting front fork tubes assemblies back on the motorcycle check all bolting is screwed according to the H-D factory service manuals!
7. Adjust the positions of the fork covers checking all clearances and fix those using fixing screws. Use the thread locker (not included).
8. Put the front wheel back on the motorcycle following H-D factory service manuals.
9. Put the fork cover caps on the top of the fork tubes. Fix those with screws and thread locker. Now the installation is complete.
10. After the installations test drive the bike to be sure everything is working perfectly.

NOTE:

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.

Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.