
Harley-Davidson V-Rod Headlight Lowering Kit 07-11

Mounting instructions



1. Check all clearances before, during and after installation.
2. Disconnect the plug from the front headlamp. Carefully dismantle the headlamp together with headlight bracket. Dismount the OEM bracket from the headlamp.
3. Put the Kit on the lower fork bracket like shown on the figures below.



(You don't need to remove the lower fork bracket from the motorcycle, on the figure it is removed for information only!)

4. Mount the headlamp back; connect the wiring plug in to the headlamp. Adjust the headlight level and the installation is complete.
5. After the installations test the lights to be sure everything is working perfectly.

NOTE:

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.

Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.