



ASSEMBLY INSTRUCTIONS

Harley-Davidson 2021-Later Sportster S
"Predator", "Sporty" Passenger Seats

SPS1/2, SPS2/2



For questions pertaining to the installation of this product, please contact our Killer Custom technical department at info@killercustom.com.

This product is manufactured in Europe by Killer Custom

NOTE: Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.

1. Check all clearances before, during and after installation.
2. To install the passenger seat, attach the mounting bracket as shown on the reference photo. Insert the bracket into the front seat and press down until the seat fits snugly into the rubber mount. You can adjust the seat's position by loosening the bracket screws to ensure the passenger seat is properly aligned and secured.



3. **Final Check:** Ensure everything is properly aligned and looks correct (picture above). Tighten all bolts securely. Enjoy your ride!

NOTE: installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.

WWW.KILLERCUSTOM.COM