
Harley-Davidson "Bobbstr" Series Softail Chin Spoiler 00-17

Mounting instructions



1. Check all clearances before, during and after installation.
2. Attach two brackets on the Chin Spoiler as shown on the picture below (use OEM bolts and washers).



3. The installation is finished.
4. After the installations test drive the bike to be sure everything is working perfectly.

NOTE:

- Installation of this kit requires detailed knowledge of the motorcycle model and mechanics. It is assumed that the installer has access to the proper tools and a working knowledge of them and factory service manuals.
- Before the painting the parts first you have to put those on the motorcycle and make sure that everything is adjusted and fits perfectly.

Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.