
2018-2023 Harley-Davidson Softail M8 Flush-Mount Fuel Cap and Left Side Tank Cap Kit

Mounting instructions



1. Check all clearances before, during and after installation.



2. Unscrew the original gas tank cap and replace it with new Flush-Mount Fuel Cap. To operate the new cap, you need to push in the middle of and spin it quarter of the turn. The middle section will raise and you will get grip surface so you can screw or unscrew it. To get the middle section back you need to push it back and spin it quarter of the turn again. There are three gaskets included so you can choose the one or combination of few which fits best.
3. For the left side of the tank use flat “fake” cap fixed with 3M™ Press-In-Place Emblem Adhesive.
4. 3M™ Press-In-Place Emblem Adhesive using instructions:
 - Clean and degrease the surfaces you want to apply the covers.
 - Remove the front liner from a sheet of 3M™ Press-In-Place Emblem Adhesive.
 - Firmly press the backing side of the Cover into the sheet of 3M™ Press-In-Place Emblem Adhesive.
 - Peel sheet away and be sure that adhesive has transferred to the backing of the Cover (will see adhesive removed on 3M™ Press-In-Place Emblem Adhesive).
 - Firmly press the back side of the Cover onto the desired location. Press lightly at first to ensure correct position, then press firmly to secure the bond. This is pressure-sensitive adhesive; press as firmly as possible without damaging the Covers or vehicle for the strongest bond.
5. As an option double sided adhesive tape can be attached to the “fake” cap, if so, just remove the protective foil and apply it on degreased surface.

Congrats! The installation is complete.
Now you are the Customizer 😊

Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.