



ASSEMBLY INSTRUCTIONS

SPORTSTER S AND NIGHTSTER EXTENSION WIRE KIT

WEXT20



For questions pertaining to the installation of this product, please contact our Killer Custom technical department at info@killercustom.com. This product is manufactured in Europe by Killer Custom

NOTE: Killer Custom assumes no responsibility or liability for damage or injury of any kind arising out of the use or misuse of any products.

Thank you for choosing our 20 cm Long Motorcycle Turn Signal Wire Extension Kit. This kit is designed for use with both Daytime Running Lights (DRL) and without them. Follow these straightforward steps to extend your turn signal wires.

Locate Your Connectors:

- Your extension wires are pre-assembled with a male and female plug.

Connect the Male Plug:

- Plug the male end into your motorcycle's connector, located behind small plastic covers on the frame.

Connect the Female Plug:

- Attach the female end to your motorcycle's turn signal plug.

Tidy Up:

- Neatly route the wires for a clean look and protection.

Final Check:

- Turn on your motorcycle to ensure turn signals work correctly.

Safety First:

- Confirm everything is secure and safe before riding.

Enjoy your extended turn signal wires!!

NOTE:

- Installation of this kit requires detailed knowledge of the motorcycle model mechanics and electrics. It is assumed that the installer has access to the proper tools and a working knowledge of them, and factory service manuals.

WWW.KILLERCUSTOM.COM